

www.QuickSilverControls.com

Date: 22 March 2018

Datasheet:QCI-DS036

# **NEMA 17 Mosolver - Motor with integrated feedback**





Internal sense coils are added inside the motor (shown symbolically in cut-away) to sense position by intercepting a portion of the flux used to operate the motor. See www.Mosolver.com for more details.

Note: Motor specifications (including torque curves) are only true when the motors are used in conjunction with QuickSilver's SilverSterling™. See the controller datasheets for more details.

Property of QuickSilver Controls, Inc. Page 1 of 6 This document is subject to change without notice. QuickControl® Mosolver™ and QCI® are Registered Trademarks of QuickSilver Controls, Inc. SilverLode™, SilverNugget™, SilverDust™, PVIA™, QuickSilver Controls™, and AntiHunt™ are trademarks of QuickSilver Controls, Inc..

# **General Motor Specifications**


Specifications	MV17L-1
Maximum Speed (RPM)	2300
48v Optimal Speed (RPM)	1700
Torque (oz-in / Nm) at Optimal Speed	18.5 0.135
Continuous Stall Torque oz-in / Nm	28 0.20
Peak Power (Mech. Watts)	27
Rotor Inertia oz-in² / Kg-m²	.18 3.29e-6
Weight lb / Kg	.61 0.27
Maximum Driver Input Current (Amps - DC)	1.1A @ 48V 1.5A @24v
Shaft Diameter in / mm	.1968 / 5.00
Maximum Axial Force lbs /N	6 26
Maximum Radial Force(lbs) @ .62" (15mm) from face	6 26

# **Torque Curves**

Torque curves represent motor torque at the specified voltage when the TQL command is set to "100%". These curves represent torque up to 100% duty cycle depending on ambient temperature, heat sinking and air flow.

"Optimal Speed" point provides the maximum available power at "100%" torque setting, which is usually the maximum efficiency point as well. If these two points differ, the "Optimal speed" is approximately the average of the two speeds.

Max speed 2300RPM @ 48v, 1800RPM @ 36v, 1400RPM @ 24v. Operation not suggested below 24v.



# **Electrical Specifications**

## **Feedback Interface**

The Mosolver utilizes an internal sense coil which determines position by measuring a portion of the flux from the chopper drive used to drive the motor. The position sensing is only active when the chopper drive is active. The sense amplifiers are within the QCI-S2-IG \*\*

## **Motor Memory**

These motors come from the factory with a memory chip containing feedback configuration and motor information. This information is automatically uploaded by the SilverSterling™ S2's controller/drivers to simplify the initialization process.

## Wiring

Motor includes 12" cable (including connector) which may connect directly to the QCI-S2-IG motor/encoder connector, or may be used with up to a 10' QCI-C-D15P-D15S-xx motor/encoder cable.

<sup>\*\*</sup> Available after S/N 2S2000


## **Connector Data**

### Standard DB-HD15 pin

		6	Motor Dhoop Au
		6	Motor Phase A+
	9 0	1	Motor Phase B+
		11	Motor Phase A-
		7	Motor Phase B-
P1	9 0	2	Motor Body Ground (option)
		12	
		8	N/C
	9 0	3	N/C
		13	Sense B+
		9	Sense A +
		4	Sense A-
		14	Logic Ground
		10	N/C
		5	Sense B-
		15	Motor Memory
	•		

Note: The motor construction uses a wave spring to compensate for mechanical tolerances and thermal expansion in the axial shaft direction. Pushing in the shaft while operating may affect sensor accuracy. High forces on the shaft will shorten bearing life and excessive levels may cause immediate failure of the shaft and/or bearings. Do NOT strike with a hammer or impact tool! Support rear shaft if pressing a gear or pulley.

# **Mechanical Specifications**



Motor Series	Body Length	Shaft diameter	Notes
MV17L-1	1.31 [33.3 mm]	0.197 [5.00 mm]	Shaft is round

# **Environmental Specifications**

### **Operational Temperature**

-10 C to +80 C

### **Storage Temperature**

-40 C to +85 C

### **Humidity**

Continuous specification is 95% RH non-condensing.

#### Shock

Limitation is approximately 50g/11ms.

### IP Rating - Standard

IP50

## **Part Numbers**

NEMA17 Mosolver				
MOTOR TYPE/SIZE	MOTOR INTERFACE			
• QCI-MV17L-1	Blank – Standard  ■ DB15HD Motor Interface Connector			
To create a part number, choose one from each column above. For example: QCI-MV17L-1				
QCI-MV17L-1				
This selection creates the part number: QCI-M17L-1				

# **Contact Information**

QuickSilver Controls, Inc. 990 N Amelia Ave San Dimas, CA 91773 909-599-6291 or (888) 660-3801 909-599-6289 FAX www.QuickSilverControls.com http://www.quicksilvercontrols.com/